



## PARKER TOUCHSCREEN CALIBRATION

DOCNUMBER  
Rev. 00  
03/10/2023  
Page 1 of 1

| REVISIONS |          |             | RESPONSIBLE |               |
|-----------|----------|-------------|-------------|---------------|
| N.        | DATE     | DESCRIPTION | CREATED BY  | CHECK/APPROVE |
| 1         | 05/10/23 | Original    | Snehal Rana |               |

# Parker XPR Touchscreen Calibration

- You will need a USB mouse. Turn off screen (switch at back of screen) and plug mouse into one of the USB ports in the back of the screen.
- Turn screen back on and wait till the RG logo comes up, press left button on mouse.
- Move mouse to system button and open.
- Open Logon.
- In user name enter tech
- In password enter tech
- (some systems have a lot of lag, be patient)
- Press Log On.
- Screen will restart, click on Shell button.
- Then go to Settings.
- Go to Calibrate Touchscreen. A window will appear, click on OK.
- Now using a finger or pen on the touchscreen touch calibration target to start.
- When you are pressing the targets, hold them down for about 3 – 5 seconds so it registers properly.
- After calibration has been finished, turn screen off, remove mouse, and back on to test.